


# PC104 V.34 FAX/MODEM



	1	2	3	4	5	6	7	8	9
COM1	●	●	●	●	●	●	●	●	●
IRQ4	●	●	■	●	●	■	■	●	●
COM2	●	■	●	●	●	●	■	■	●
IRQ3	●	■	●	●	●	●	■	■	●
COM3	●	●	●	●	●	●	●	●	●
IRQ4	●	●	■	●	●	■	●	●	■
COM4	●	●	●	●	●	●	●	●	●
IRQ3	●	■	●	●	●	●	■	●	■

- 1-IRQ2
- 2-IRQ3
- 3-IRQ4
- 4-IRQ5
- 5-IRQ7
- 6~9 I/O port address select

**J6: Jump setting the COM port and IRQ of Fax/Modem Card**